

SCHEDA TECNICA / DATA SHEET

DATA DI EMISSIONE / DATE OF ISSUE 18/01/2023 Ed: 342314



PASTIGLIE LAVASTOVIGLIE

Con olio essenziale di menta ed eucalipto – 25 PASTIGLIE CON INVOLUCRO IDROSOLUBILE

DISHWASHING TABLETS

with essential oils of mint and eucalyptus - 25 TABS WITH WRAP WATER SOLUBLE



CARATTERISTICHE / PROPERTIES:

- 78 % Ingredienti di origine naturale
- 78 % natural ingredients
- Senza profumi di sintesi
- Without synthetic perfumes
- Astuccio in carta riciclata 100 %
- 100 % recycled paper box

COMPOSIZIONE CHIMICA:

5-15%: Sbiancanti a Base di Ossigeno; < 5%: Tensioattivi Non Ionici. Altri Componenti: Policarbossilati, Enzimi, Eucalyptus Globulus Leaf Oil, Mentha Arvensis Leaf Oil

CHEMICAL COMPOSITION:

(Reg. CE 648/2004 and subsequent modifications)
5-15%: Oxygen-Based Bleaching Agents; < 5%: Non Ionic Surfactants. Other Components: Polycarboxilates, Enzymes, Eucalyptus Globulus Leaf Oil, Mentha Arvensis Leaf Oil.



Prodotto certificato ICEA ECO DETERGENZA
Certified product ICEA ECO CLEANERS



Prodotto certificato THE VEGAN SOCIETY UK
Certified product THE VEGAN SOCIETY UK

INGREDIENTS: Sodium Citrate, Sodium Carbonate, Sodium Carbonate Peroxide, Sodium Sulfate, Sodium Chloride, Sodium Silicate, Tetraacetyl Ethylene Diamine (TAED), Citric Acid, Sodium Bicarbonate, Tetrasodium Iminodisuccinate, Microcrystalline Cellulose, Cetareth-25, D-pentose Oligomeric, C10 and C12 Alkyl Glycosides, Subtilisin, Amylase, Eucalyptus Globulus Leaf Oil*, Mentha Arvensis Leaf Oil*.

*da Agricoltura Biologica / from Organic Farming

CODICE UFI: A9J5-40Y7-K006-P0T8



ATTENZIONE:

Provoca grave irritazione oculare.
Contiene: Subtilisin. Può provocare una reazione allergica. Tenere fuori dalla portata dei bambini. In caso di consultazione di un medico, tenere a disposizione il contenitore o l'etichetta del prodotto. IN CASO DI CONTATTO CON GLI OCCHI: sciacquare accuratamente per parecchi minuti. Togliere le eventuali lenti a contatto se è agevole farlo. Continuare a sciacquare. Proteggere gli occhi / il viso. Se l'irritazione degli occhi persiste, consultare un medico.

WARNING:

Causes serious eye irritation. Contains: Subtilisin. May cause allergic reactions. Keep out of reach of children. If medical advice is needed, please have the product container or label. IF IN EYES: rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue to rinse. Wear eye protection/face protection. If irritation of the eyes persists, get medical advice/attention.

MODO D'USO:

DA UTILIZZARE ESCLUSIVAMENTE PER MACCHINE LAVASTOVIGLIE.

1. Rimuovi i residui alimentari di grandi dimensioni da piatti e posate. 2. Carica la macchina lavastoviglie secondo le istruzioni del produttore. 3. Per una corretta conservazione del prodotto, preleva sempre con MANI ASCIUTTE la pastiglia dall'astuccio. 4. Inserisci la pastiglia nella vaschetta ASCIUTTA del detersivo senza scartarla: la bustina si dissolve durante il lavaggio. 5. Non introdurre la pastiglia se non effettui il lavaggio immediatamente. 6. Seleziona il ciclo di lavaggio desiderato e avvia la lavastoviglie. 7. 1 tabs è sufficiente qualunque sia la condizione dell'acqua. 8. Non far funzionare la lavastoviglie con il programma corto. 9. Utilizzare il programma normale di lavaggio (50°-65°) 10. Alcuni articoli non sono adatti per la pulizia in lavastoviglie. Non lavare in lavastoviglie i seguenti materiali: legno, alluminio, cristallo, porcellana dipinta a mano e stoviglie con decori dorati e argentati, alcuni materiali plastici che non possono resistere a temperature fino 70° C.

PER RIDURRE AL MASSIMO GLI SPRECHI È CONSIGLIABILE:

utilizzare la lavastoviglie il più possibile a pieno carico • se presente, usare il programma ecologico della lavastoviglie • pulire spesso il filtro della lavastoviglie evitando di introdurre stoviglie con residuo di cibo • controllare che l'apposito contenitore del sale sia sempre pieno.

HOW TO USE:

TO BE USED ONLY IN DISHWASHERS.

1. Remove large food residues from the crockery and cutlery. 2. Load the dishwasher according to the manufacturer's instructions. 3. For the correct conservation of the product, always remove the tab from the packet with DRY HANDS. 4. Place the tab in the DRY detergent dispenser without removing the wrapping, which will dissolve during the wash cycle. 5. Do not place the tab in the dispenser if you do not intend to start the dishwasher immediately. 6. Select the desired wash cycle and start the dishwasher. 7. One tab is sufficient, whatever the condition of the water. 8. Do not operate the dishwasher on the short wash cycle. 9. Use the normal wash cycle (50°-65°). 10. Some articles are not suitable for washing in the dishwasher. Do not wash the following materials in the dishwasher: wood, aluminium, crystal, hand-painted porcelain and crockery with gold-plated and silver-plated decorations, plastic materials that are not resistant to temperatures up to 70°C.

TO MINIMIZE WASTE IT IS ADVISABLE:

use the dishwasher with a full load whenever it's possible • if present, use the dishwasher's ecological program • often clean the dishwasher filter, avoiding placing dishes with food residues in it • check that the special salt container is always full.

CONFEZIONI / PACKAGES

COD. ARTICOLO CODE ARTICLE	DESCRIZIONE DESCRIPTION	gr	PZ CARTONE PIECES X CARDBOARD	COD EAN EAN CODE
592581	PIERPAOLI EKOS PASTIGLIE LAVASTOVIGLIE PIERPAOLI EKOS DISHWASHING TABLETS	18	16	8002849925812

PALLETTIZZAZIONE / PALLETIZATION

DIM. BOX mm (l x p x h)	DIM. CARTONE mm (l x p x h)	PESO CARTONE kg CARDBOARD WEIGHT kg	CARTONI X STRATO CARDBOARDS X LAYER	STRATI X PALLET LAYERS X PALLET	CARTONI X PALLET CARDBOARDS X PALLET
145x50x135	298x398x149	8,60	8	10	80