Typhoon 500_User Manual *iDance version 16-5-2022

FRONT

420 x 297 mm

iDance HK
iDance International Ltd.
Unit I, 6/F., MG Tower,
133 Hoi Bun Road,
Kwun Tong, Kowloon
Hong Kong

iDance Germany
RBM Trading GmbH
Beckedorfer Str 13
21218 Seevetal
Germany

iDance UK
iDance International UK Ltd.
85 Great Portland Street
London W1W 7LT
United Kingdom

Copyrights 2022 iDance International Limited - All Rights Reserved

www.idanceintl.com

TYPHOON 500

- Wireless SOUND and LIGHT PARTY System
- Bring the Party anywhere: Totally Portable and Wireless
- Bring the Party anywhere: Totally Portable and Wireless
- Bring the Party anywhere: Totally Portable and Wireless
- Bring the Party anywhere: Totally Portable and Wireless
- Bring the Party anywhere: Totally Portable and Wireless
- Bring the Party anywhere: Totally Portable and Wireless
- Bring the Party anywhere: Totally Portable and Wireless



- User Manual
- Mode d'emploi
- Bedienungsanleitung
- Gebruikershandleiding
- Manual del usuario
- Manuale dell'utente
- Manual do utilizador
- Brugsanvisning

ENGLISH • FRANÇAIS • DEUTSCH • NEDERLANDS • ESPAÑOL • ITALIANO • PORTUGUESE • DANISH

Thanks for your Purchase of iDance TYPHOON 500, Please read the manual with attention before use	Merci de l'achat de votre iDance TYPHOON 500, bien lire ce manuel avant son utilisation	Hartelijk bedankt voor het aanschaffen van de iDance TYPHOON 500, lees de handleiding a.u.b. zorgvuldig door vóór ingebruikname	Vielen Dank, dass Sie sich für iDance TYPHOON 500 entschieden haben. Bitte lesen Sie die Bedienungsanleitung vor der Verwendung aufmerksam durch.
Gracias por comprar el iDance TYPHOON 500. Lea atentamente el manual antes de utilizarlo.	Grazie per aver acquistato iDance TYPHOON 500, leggere attentamente il manuale prima dell'uso.	Obrigado por ter adquirido a iDance TYPHOON 500. Leia atentamente o manual antes da utilização	Tak fordi du valgte at købe denne iDance TYPHOON 500. Læs vejledningen omhyggeligt inden ibrugtagning

WARNING • AVERTISSEMENT • WAARSCHUWING • WARNUNG • ADVERTENCIA • ATTENZIONE • AVISO • ADVARSEL

NOTES / Remarque / Nota / ANMERKUNGEN / Notas / NOTE / NOTAS / NOTER:

IMPORTANT SAFETY INSTRUCTIONS • INSTRUCTIONS IMPORTANTE DE SECURITE • BELANGRIJKE VEILIGHEID INSTRUCTIES • WICHTIGE SICHERHEITSHINWEISE • INSTRUCCIONES DE SEGURIDAD IMPORTANTES • IMPORTANTI ISTRUZIONI DI SICUREZZA • INSTRUÇÕES DE SEGURANÇA IMPORTANTES • VIGTIGE SIKKERHEDSINSTRUKTIONER

• La palabra, marca y logotipo de Bluetooth® son marcas registradas propiedad de Bluetooth SIG, Inc. y cualquier uso de tales marcas por iDance es bajo licencia. Otras marcas comerciales y nombres comerciales son propiedad de sus respectivos dueños.

• A palavra, a marca e o logótipo do Bluetooth® são marcas registadas da Bluetooth SIG, Inc. e qualquer uso de tais marcas pela iDance está sob licença. Outras marcas registadas e nomes comerciais pertencem aos respetivos proprietários.

• La parola, il marchio e il logo Bluetooth® sono marchi registrati di proprietà di Bluetooth SIG, Inc. e qualsiasi utilizzo di tali marchi da parte di iDance è concesso in licenza. Altri marchi e nomi commerciali appartengono ai rispettivi proprietari.

• Ordet, mærket og logoet Bluetooth® er registrerede varemærker, der ejes af Bluetooth SIG, Inc., og enhver brug af sådanne mærker fra iDance sker under licens. Andre varemærker og handelsnavne tilhører deres respektive ejere.



English	French	German	Dutch	Spanish	Italian	Portugase	Danish
Technical Specifications	Spécifications techniques	Technische specificaties	Technische Spezifikationen	Specifiche tecniche	Specifiche tecniche	Especificações técnicas	Tekniske specifikationer
Speaker size: 2x 8"	Taille du haut-parleur: 2x 8 "	Lautsprechergröße: 2x 8 "	Luidsprekerformaat: 2x 8 "	Tamaño del altavoz: 2x 8 "	Dimensioni altoparlante: 2x 8 "	Tamanho do alto-falante: 2 x 8 "	Højttalerstørrelse: 2x 8 "
Musical Max Power: 500 Watts	Puissance max: 500 Watts	Max. muziekvermogen: 500 Watts	Max. Ausgangsleistung: 500 Watts	Potencia musical máx.: 500 Watts	Potenza musicale massima: 500 Watts	Potência máxima da música: 500 Watts	Maks. Udgangseffekt: 500 Watts
RMS Power: 8 Watts	Puissance RMS: 8 Watts	RMS-Leistung: 8 Watt	RMS-vermogen: 8 watt	Potencia RMS: 8 vatios	Potenza RMS: 8 Watt	Potência RMS: 8 Watts	RMS-effekt: 8 watt
Power consumption: 8 Watts	Consommation électrique: 8 Watts	Leistungsaufnahme: 8 Watt	Stroomverbruik: 8 Watt	Consumo de energía: 8 Watts	Consumo energetico: 8 Watt	Consumo de energia: 8 Watts	Strømforbrug: 8 Watt
Speaker Impedance 3 ohms	Impédance du haut-parleur 3 ohms	Luidsprekerimpedantie 3 ohm	Lautsprecherimpedanz 3 Ohm	Impedancia del altavoz 3 ohmios	Impedenza dei diffusori 3 ohm	Impedância do Alto-falante 3 ohms	Højttalerimpedans 3 ohm
S/N Ratio: 75 dB	Rapport S/N: 70 dB	Signaal/ruisverhouding: 70 dB	Rauschabstand: 70 dB	Relación S/R: 70 dB	Rapporto segnale/rumore: 70 dB	Relação sinal-ruído: 70 dB	S/N-forhold: 70 dB
Frequency: 20Hz~20kHz	Fréquence: 100Hz~20kHz	Frequentie: 100Hz~20kHz	Frequenzbereich: 100Hz~20kHz	Frecuencia: 100Hz~20kHz	Frequenza: 100Hz~20kHz	Frequência: 100Hz~20kHz	Frekvens: 100Hz~20kHz
Charging Time: 4 hours	Temps de charge: 4 heures	Oplaadtijd: 4 uur	Ladedauer: 4 heures	Tiempo de carga: 4 horas	Durata della ricarica: 4 ore	Tempo de carregamento: 4 horas	Ladetid: 4 timer
Playing Time: 2-4h	Autonomie: 2-4h	Speelduur: 2-4 u	Wiedergabedauer: 2-4h	Tiempo de reproducción: 2-4h	Tempo di riproduzione: 2-4 ore	Tempo em reprodução: 2-4h	Afspilningstid: 2-4 t
BT Wireless Version: 5.0	Version BT Wireless: 5.0	BT Wireless-versie: 5.0	BT Wireless-Version: 5.0	Versión de BT Wireless: 5.0	Versione BT Wireless: 5.0	Versão do BT Wireless: 5.0	BT Wireless-version: 5.0
BT Wireless Frequency: 2.4 GHZ	Fréquence BT Wireless: 2,4 GHz	BT Wireless-frequentie: 2,4 GHZ	BT Wireless-Frequenz: 2,4 GHz	Frecuencia BT Wireless: 2.4 GHZ	Frequenza BT Wireless: 2,4 GHZ	Freqüência BT Wireless: 2.4 GHZ	BT Wireless-frekvens: 2,4 GHz
Input: 5v/ 1A	Alimentation en entrée: 5v/ 1A	Invoer: 5v/ 1A	Eingang : 5v/ 1A	Corriente: 5v/ 1A	Alimentazione: 5v/ 1A	Entrada: 5v/ 1A	Indgang: 5v/ 1A
Output (V,A): 9V 1.3A	Sortie (V, A): 9V 1.3A	Ausgang (V, A): 9 V 1,3 A.	Uitgang (V, A): 9V 1.3A	Salida (V, A): 9 V 1,3 A	Uscita (V, A): 9 V 1,3 A.	Saída (V, A): 9V 1,3A	Udgang (V, A): 9V 1,3A
Battery Type: 18650 lithium	Type de batterie: 18650 Lithium	Batterijtype: 18650 Lithium	Akkutyp: 18650 Lithium	Tipo de batería: 18650 litio	Tipo di batteria: 18650 Litio	Tipo de bateria: Lítio 18650	Batteritype: 18650 lithium
Battery Capacity: 7.4V 2000 mah	Capacité de la batterie: 7,4 V 2000 mah	Batteriekapazität: 7,4 V 2000 mah	Batterijcapaciteit: 7,4 V 2000 mah	Capacidad de la batería: 7,4 V 2000 mah	Capacità della batteria: 7,4 V 2000 mah	Capacidade da bateria: 7,4 V 2000 mah	Batterikapacitet: 7.4V 2000 mah
Dimensions: 625 Height x 217 Diameter in mm	Dimensions: 625 Hauteur x 217 Diamètre en mm	Abmessungen: 625 Höhe x 217 Durchmesser in	Afmetingen: 625 Hoogte x 217 Diameter in mm	Dimensiones: 625 Alto x 217 Diámetro en mm	Dimensioni: 625 Altezza x 217 Diametro in mm	Dimensões: 625 Altura x 217 Diâmetro em mm	Dimensioner: 625 Højde x 217 Diameter i mm
Net Weight: 3 kgs	Poids net: 3 kg	Nettogewicht: 3 kg	Nettogewicht: 3 kg	Peso neto: 3 kgs	Peso netto: 3 kg	Peso líquido: 3 kgs	Nettovægt: 3 kg

English	French	German	Dutch
What is included in the Box	Inclus dans la boite	Im Lieferumfang enthalten	bevat in de doos
1 pc main unit TYPHOON 500	un TYPHOON 500	1x TYPHOON 500	1x TYPHOON 500
1 pc Wired Microphone	un Micro filaire	1x Kabelgebundenes Mikrofon	1x bedrade microfoon
1 pc Remote Control	Télécommande 1 pc	1 Stk. Fernbedienung	1 pc afstandsbediening
1 pc Power Supply Adaptor	1 adaptateur d'alimentation	1 St. Netzteiladapter	1 st voedingsadapter
1 pc Instruction Manual	un Manuel d'instruction	1x Bedienungsanleitung	1x handleiding

Spanish	Italian	Portuguese	Danish
incluye en la caja	include nella confezione	inclui na caixa	inkluderer i kassen
1x TYPHOON 500	1x TYPHOON 500	1x TYPHOON 500	1x TYPHOON 500
1x micrófono con cable	1x microfono cablato	1x microfone com fio	1x kabelforbundet mikrofon
Control remoto de 1 pc	Telecomando da 1 pz	1 pc controle remoto	1 stk Fjernbetjening
Adaptador de fuente de alimentación de 1 pieza	Adattatore di alimentazione da 1 pz	Adaptador de alimentação de 1 pc	1 stk. Strømforsyningsadapter
1x manual de instrucciones	1x manuale di istruzioni	1x Manual de instruções	1x Instruktionsmanual

Copyrights 2022 iDance International Limited - All Rights Reserved

BACK

420 x 297 mm

	English	French	German
	Configuration Panel	Interface utilisateur	Benutzeroberfläche
1	Power Switch and Master Volume Control	Interrupteur d'alimentation et contrôle du volume principal	Netzschalter und Hauptlautstärkeregler
2	AC Adaptor dock to connect to the included Power Supply	Station d'accueil pour adaptateur secteur pour se connecter au bloc d'alimentation inclus	[illegible]
2	red led to indicate the battery status.	led rouge pour indiquer l'état de la batterie.	rote LED zur Anzeige des Batteriestatus.
2	Red Led is on when unit is low battery and charging	La LED rouge est allumée lorsque la batterie est faible et en charge	[illegible]
2	Red led is OFF when unit is fully charged	La LED rouge est éteinte lorsque l'unité est complètement chargée	[illegible]
3	MIC input - 6.35mm Jack input to connect your dynamic microphone	Entrée Micro 6.35mm / Jack pour votre micro Dynamique	[illegible]
4	AUX IN - Audio input to connect your external source	AUX IN - Entrée Audio pour connecter vos sources externes	[illegible]
5	USB/ TF port - Read MP3 files up to 32G capacity (FAT32)	Port USB/ Carte TF - lit les fichiers MP3 FAT32 pour capacite max de 32G	[illegible]
6	Microphone Volume Control	Contrôle du volume du microphone	Mikrofonlautstärkeregler
7	Echo effect Volume Control for the micr input	Contrôle du volume de l'effet d'écho pour l'entrée micro	[illegible]
8	Digital Display	Affichage numérique	Digitaler Bildschirm
9	MODE button: BT Wireless, AUX IN, USB MP3 Player	Bouton MODE: BT Wireless, AUX IN, lecteur MP3 USB	[illegible]
9	Press to select your different audio sources	Appuyez pour sélectionner vos différentes sources audio	[illegible]
9	Hold button to power on /off the leds into the woofer	Maintenez le bouton enfoncé pour allumer / éteindre les LED dans le woofer	[illegible]
10	PLAY / SHARING mode - Press to Play/Pause	PLAY / SHARING MODE - Appuyer pour Jouer/arreter,	[illegible]
10	press button for 3 seconds to access to SHARING MODE: Same smart Device can play to 2 of the same speaker using the BT Wireless	[illegible]	[illegible]
11	PREV - go to previous song	[illegible]	[illegible]
11	Hold the button 2 seconds to decrease the volume of the MP3 Player	[illegible]	[illegible]
12	NEXT- go to next song	[illegible]	[illegible]
12	Hold the button 2 seconds to increase the volume of the MP3 Player	[illegible]	[illegible]
	BT Wireless CONNECTION	[illegible]	[illegible]
	the BT Wireless 's pairing name is: "TYPHOON 500 "	[illegible]	[illegible]
	If your device cannot search for "TYPHOON 500 ", please ensure that the speaker is in BT Wireless mode. If still have BT Wireless connection problems, please switch off both BT Wireless device and BT Wireless speaker. Then start again, to scan for BT Wireless device.	[illegible]	[illegible]
	If you want to convert the other device BT Wireless, please disconnect the playing device from the BT Wireless speaker (disconnect tone "beep" sound), and then connect the next device.	[illegible]	[illegible]
	To Disconnect the BT Wireless mode, you must disconnect the BT Wireless pairing on the current used smart device	[illegible]	[illegible]
	SHARING mode	[illegible]	[illegible]
	SHARING mode, Same Audio Source to 2x iDance Speakers (same item number)	[illegible]	[illegible]
	Turn on the 2 units together at the same time	[illegible]	[illegible]
	Then, connect one of them to your BT Wireless smart device you will be able to play the same smart device to 2x DJX100mk2 in wireless mode.	[illegible]	[illegible]
	USB MP3 Player	[illegible]	[illegible]
	Insert MP3 music files into USB and plug in the USB port, the machine will play the music files automatically.	[illegible]	[illegible]
	The unit is designed to play MP3 and WAV audio files contained in a USB key. If the files are not in MP3 or WAV format, the files cannot be read successfully.	[illegible]	[illegible]
	Trouble Shooting	[illegible]	[illegible]
	The unit is not Starting	[illegible]	[illegible]
	the sound is distorsed	[illegible]	[illegible]
	Charge it for a least 4 hours	[illegible]	[illegible]
	the audio sound is cutting from your BT Wireless	[illegible]	[illegible]
	unpair and repair your smart device	[illegible]	[illegible]
	USB / TF card is not playing	[illegible]	[illegible]
	check if you only have audio files on these mass storage device	[illegible]	[illegible]
	unplug USB / TF card, and and replug them	[illegible]	[illegible]
	if the problem stiill persist, refer to an appointed service agent, and DO NOT OPEN the speaker cover	[illegible]	[illegible]
	Microphone or guitar are not playing	[illegible]	[illegible]
	Check the volume or the connexion, be sure your microphone is Powered on	[illegible]	[illegible]
	if the unit is not starting, fully charge for 6 hours, using the included power supply adaptor	[illegible]	[illegible]
	Design and spefications are subject to change without notice	[illegible]	[illegible]
	iDance is a registered trademark in Europe and other countries	[illegible]	[illegible]
	all other product or company names are trademarks or registered trademarks of their respective owners.	[illegible]	[illegible]
	Copyrights iDance International Limited, all rights reserved	[illegible]	[illegible]
	For more info please contact: info@idanceintl.com	[illegible]	[illegible]

Copyrights 2022 iDance International Limited - All Rights Reserved